


Push To Start Shut-off Screw Driver



Part No.	Description	Qty	Part No.	Description	Qty	Part No.	Description	Qty
01-102-03	ROTOR BLADE	6	21-702-01	WASHER	1	63-701-01	SWITCH ROD	1
02-200-01	O-RING (P2)	1	25-702-13	AIR INLET (PT)	1	74-703-07	DRIVING ROD	1
02-200-03	O-RING (P3)	1	26-703-05	MUFFLER	1	74-709-05	ANVIL	1
02-200-07	O-RING (P8x1.5)	1	26-902-02	MUFFLER	1	75-607-08	FRONT CAP	1
02-201-07	O-RING (S14)	1	31-706-01	HOOK	1	78-610-02	HANDLE	1
02-203-06	O-RING (P28x2)	1	32-715-04	DRIVER	1			
03-700-07	STEEL BALL(ϕ 3.175mm)	1	35-706-03	ROTOR	1			
04-700-01	PIN (ϕ 3x4)	1	36-503-06	FRONT PLATE	1			
04-700-03	PIN (ϕ 2x6)	1	37-503-03	REAR PLATE	1			
04-701-05	PIN (ϕ 4x15)	6	38-503-05	CYLINDER	1			
04-701-08	PIN (ϕ 2x18)	1	39-701-08	BOLT	1			
06-700-07	SPRING	1	48-703-01	GEAR RING	2			
06-701-10	SPRING	1	49-702-09	GEAR SEAT	1			
06-702-09	SPRING (d: ϕ 3.5)	1	51-303-01	BUSHING	1			
08-701-08	SPRING	1	51-403-02	BUSHING	1			
08-701-09	SPRING	2	51-605-03	BUSHING	1			
09-701-01	STOPPING WHEEL	1	51-701-07	BUSHING	1			
12-700-06	RETAINING RING	1	51-702-09	BUSHING	1			
12-701-08	RETAINING RING	1	51-702-10	BUSHING	1			
15-701-07	BALL BEARING (626-2Z)	1	51-702-21	BUSHING	1			
15-702-04	BALL BEARING (R6)	1	52-701-03	WASHER	1			
15-703-01	BALL BEARING (6201-2Z)	1	52-701-17	WASHER	1			
16-701-02	GEAR	6	52-702-10	WASHER	1			
16-701-08	GEAR	1	52-702-24	WASHER	1			
18-703-03	REVERSE VALVE	1	55-701-01	DRIVER	3			